

Yield Advantages Through Maintaining and Upgrading FOUP Populations

White paper

INTRODUCTION

One of the longest held beliefs in semiconductor manufacturing is that yield is the single most important factor in overall wafer processing costs. Even incremental yield increases can significantly reduce manufacturing cost per wafer, or cost per square centimeter of silicon. As such, yield improvement is critical to any successful semiconductor operation.¹ As semiconductor device nodes continue to scale, and 7 nm lines are ramping to production, this belief continues to ring true.

Today's fine geometries and vertical structures, such as FinFET logic devices and 3D NAND flash memory, are even more prone to yield hits due to process variability and contamination. These risks are tied not only to device design, but the equipment and processes being used to manufacture them. For example, an excursion – that is, when a process or piece of equipment moves out of preset specifications – can be a significant contributor to yield loss, particularly if it goes undiscovered until after fabrication.² Therefore, steps that assure wafer defect reduction are critical to yield management.

Over 20 years ago, the semiconductor manufacturing industry moved to factory automation, not only to increase device throughput, but also to mitigate yield risk caused by human interaction with wafers. Wafer transport and handling systems became an essential part of the manufacturing process flow to maintain a clean environment for the wafers. These systems comprise three types of wafer handling carriers: Front opening shipping boxes (FOSB) for transporting from the wafer supplier to the fab; front opening unified pods (FOUPs) for transport within the fab; and horizontal wafer shippers (HWS) for transport to final assembly. This paper focuses specially on FOUPs, and how yield advantages can be achieved simply through proper maintenance and upgrades of your FOUP fleet.

A FOUP'S FAB JOURNEY

FOUPs were originally designed to serve as a wafer transport carrier from the FOSB, and then from process chamber to process chamber. They had shock-absorbing capabilities, humidity control, and were designed to minimize particle contamination. As technology nodes continued to shrink past 10 nm to 7 nm development, the industry needed modified FOUP capabilities to keep these delicate and costly wafers safe. Some of these modifications included a change in FOUP materials for the shells, gaskets, and valves. Advanced purge capabilities were also necessary for 7 nm node processes and beyond to prevent contamination during copper etch processes.

As a result, today's FOUPs not only address particles, but also minimize and control volatile organic compounds (VOCs), oxygen, and relative humidity. Any of these potential contamination sources can negatively impact device yield.³ In fact, FOUPs are one of the most important devices a fab has, because they provide a hyper-clean microenvironment for the wafers they are protecting.

These FOUPs offer a sealed wafer environment that provides static protection, white-light shielding, and control moisture and oxygen. The purge ports make it possible to fill the FOUP with nitrogen during processing and storage. Advanced purge capabilities allow for uniform airflow across the wafer surface by bringing air from the bottom of the box and along the vertical access. In this way, the wafers are bathed in nitrogen as they are processing into and out of the FOUP, keeping oxygen and moisture concentrations low. This prevents the opportunity for excessive etching or corrosion.⁴ This is important because as wafers exit a process, residual gas or other materials may remain on the surface that may continue to outgas. If these are not removed from the wafer surface, they will continue to react inside the FOUP, and can result in defects forming on the wafer.

A wafer will travel 8 to 16 km as it moves through the process steps. FOUPs are one of the most important devices a fab has because they provide a hyper-clean microenvironment for the wafers they are protecting throughout the journey.



Figure 1. Aesthetic issues on aging FOUPs include (Top to bottom, L-R): scratched doors, dented door at load port key interface, top shell scratches, top shell dents, gasket area dents, deformation on gaskets.

A wafer will travel 8 to 16 km within the fab as it moves through the process steps required to manufacture each microchip. In advanced microprocessor manufacturing, there can be up to 400 steps with the FOUP docking at between 100 and 200 process tools, and with door open periods of up to 30 minutes. Each step creates a significant risk for yield-impacting contamination. As such, without careful maintenance, FOUP fleets begin to show the effects such as broken or improperly installed wafer retainers, cassettes, and filter assemblies; pinched or deformed door gaskets; shell scratches or cracks; cracked or damaged door housing; contamination from metal, chemicals, broken wafers, and process issues, such as post-etch copper contamination, Figure 1.

THE IMPORTANCE OF FOUP MAINTENANCE

With proper maintenance and regular refurbishment, FOUP fleets can last for years. There are times where it is necessary to purchase new FOUPs, such as when they are beyond repair or are too old to retrofit with new parts, when a new fab is under construction, or an existing fab is undergoing expansion. However, many legacy fabs are not pursuing finer process nodes or vertical structures, and do not need new technology. For FOUPs that are in good working order, it is possible to cost-effectively maximize their longevity while also improving yield. Additionally, for fabs moving to finer nodes that have FOUPs in the field purchased within the last five years, these can be updated with new technology while keeping the fleet in circulation.

Advanced FOUPs with shells made from proprietary barrier materials, with novel gasket designs, "umbrella" valves vs. spring-loaded-metal ones, and state-of-the art purge diffusers go a long way in preventing latent defectivity in wafers, resulting in yield improvements of 3.5% or more. Moreover, the cost of an upgrade kit versus a new FOUP represents more than 5X savings. It is therefore beneficial and cost-efficient to properly maintain and upgrade these FOUP fleets, versus replacing them.

STEPS FOR PROPER FOUP MAINTENANCE

Analysis shows that after several years of use, FOUPs begin to show signs of degradation and general wear. Gaskets and O-rings become deformed, filters and components are damaged, and microcracks caused by accidental mishandling begin to appear. Additionally, dimensions can move out of specification. This significantly impacts FOUP cleanliness and proper function. Routinely washing a FOUP will remove many surface particles, but there are still chances that particles or other forms of contamination get by a deformed gasket, O-ring, filter, or damaged component. That is why a regular FOUP maintenance program is critical for ensuring that the FOUP environment is consistently and constantly clean.

It is helpful for semiconductor manufacturing companies to have either a dedicated area in which to perform regular and systematic FOUP maintenance, or contract with a service provider for this task. Table 1 describes FOUP maintenance steps in more detail, including frequency, to make sure a FOUP is properly maintained. In parallel to the regular maintenance program described here, FOUPs that have experienced excursions on the production floor should also be evaluated. These excursions could include a fall from the load port, being hit during the automation process, increases in chemical deviation from the wafers, etc. They are examined for broken doors, diffusers, and seals and repaired if possible. Companies that follow this maintenance protocol have reported that after 13 years of use, FOUP fleets are still being used successfully.

PREVENTIVE MAINTENANCE	FREQUENCY	ACTION	
Visual inspection	Prior to every cleaning.	Visually inspect the FOUP for damage and excessive wear and tear. Replace any worn or damaged components.	
Functional inspection	Prior to every cleaning.	Check the function and torque of the door's latching system to make sure that it is functioning per the FOUP manufactures recommendations.	
Dimensional inspection	Every three months; and when a failure is identified in the visual or functional inspection, or after a tool interface failure.	Inspect the FOUPs door dimensions and the shells front flange position, registration, and key slots and wafer positions to ensure that they are within specifications.	
Conductance test	Every six months; and when a failure is identified in the visual or functional inspection.	Perform a conductance test according to FOUP manufacturer recommendations to identify damaged gaskets, O-rings, door, or shell.	
Door gasket replacement	Every year; and after any failed conductance test.	Replace the door gasket.	
Breather filter and purge module assemblies	Every year; and after any failed conductance test.	Replace the breather filter assembly or purge assembly, including all filters, O-rings, and cartridges where necessary. Check valves and/or grommets.	
Door replacement	The FOUP door should only be replaced if it is damaged, or if functional, dimensional, or conductance issues cannot be corrected by replacing the gasket.	Replace damaged door with a new door and repeat functional, dimensional, and conductance test.	
Cleaning and drying	Depending on the process, prior to the start of each new wafer lot and after any preventive maintenance.	Wash and dry the FOUP using approved methods and recommendations from cleaning tool supplier and FOUP manufacturer.	

Table 1. Recommended FOUP Maintenance

FOUP REFURBISHMENT SAVES COMPANIES \$1.2 - 2M

Every manufacturing facility with 7 nm production lines is now running FOUP fleets outfitted with the latest technologies. Facilities currently running legacy node lines, such as 65 nm and 45 nm, that ramp to more advanced nodes will benefit from utilizing the new technologies and designs of these more advanced FOUP platforms. However, replacing an entire FOUP fleet can be a multimillion-dollar expense and outside available budgets. Fortunately, there are retrofit solutions for certain situations.

That said, investing in a new fleet does have key advantages. The latest FOUP platforms enable upgradeable features so fabs can decide which technologies to invest in now, and which can be retrofitted later. Studies show that companies who invest in upgrading their FOUP fleet with purge and other leading technologies achieve upwards of three die-per-wafer increases.

In one instance, a previous generation FOUP fleet was outfitted with metal spring check valves used to regulate purge pressure. Over time, these springs became corroded, causing metal particulates that could cause wafer defects. By retrofitting FOUPs in the field with a new umbrella valve without metal springs, the particulate potential was eliminated.

After retrofitting its entire FOUP fleet in the field with purge modules in 2019, one company reported yield improvements of \$139M devices annually. At yet another fab, the original goal was to address a particle issue. Upon inspection, it was found that the front door seal gasket was shedding particles due to its contact rotation notch on the door housing. The solution was to replace a defined set of FOUPs with new gaskets, which cost considerably less than

Table 2. Yield Improvement Effect on Profit

replacing the entire door. The results yielded an increase in die per wafer and led the fab to implement a preventive maintenance program that calls for changing out the door seal gaskets annually.

Calculations show that even a 1% yield improvement, Table 2, can result in greater than \$100 million in bottom-line profit for the device manufacturer.⁵

CONCLUSION

It is well understood that yield management is critical to semiconductor manufacturing success. If yields are dropping, FOUP maintenance or upgrades may be beneficial. Many fabs ignore FOUP maintenance, not realizing the impact it can have on final yields, and as a result, the bottom line. While FOUPs will degrade over time, full replacement of a fab's FOUP fleet is a costly endeavor. It is important, therefore, for every semiconductor manufacturer to evaluate their FOUP maintenance protocol and determine if improvements should be made.

ABOUT ENTEGRIS

Entegris is a leader in specialty chemicals and advanced materials solutions for the microelectronics industry and other high-tech industries. Entegris is ISO 9001 certified and has manufacturing, customer service, and/or research facilities in the United States, China, France, Germany, Israel, Japan, Malaysia, Singapore, South Korea, and Taiwan. Additional information can be found at <u>www.entegris.com</u>

Device type	Die size	Total dies per 300 mm wafer	1% Yield dies improvement	ASP	Fab wspm	Total revenue for 1% yield improvement (\$M)
Logic (Apple A11 Bionic)	87.66 ³ mm	806	8	\$27.50 ⁴	60,000	\$159,659,861
3D-NAND (512 GB)	129⁵ mm	548	5	\$20.00 ⁶	60,000	\$78,905,051

Source: Entegris estimate

References

- ¹ Yield and Yield Management, in Cost Effective IC Manufacturing, Integrated Circuit Engineering Corporation, Scottsdale, AZ: 1997 <u>http://smithsonianchips.si.edu/ice/cd/CEICM/SECTION3.pdf</u>
- ² K. De Backer, R.J. Huang, M. Lertchaitawee, M. Mancini, and C.L Tan, *Taking the Next Leap Forward in Semiconductor Yield Improvement*, p,1; McKinsey and Co, April 2018. <u>https://www. mckinsey.com/~/media/McKinsey/Industries/Semiconductors/ Our%20Insights/Taking%20the%20next%20leap%20forward%20 in%20semiconductor%20yield%20improvement/Taking-the-nextleap-forward-in-semiconductor-SHORT.ashx</u>
- ³⁻⁵ Realizing Bottom Line Profits from Wafer Carrier Selection, Entegris, September 2018. <u>https://info.entegris.com/white-paper-realizing-bottom-line-profits-from-wafer-carrier-selection</u>

FOR MORE INFORMATION

Please call your Regional Customer Service Center today to learn what Entegris can do for you. Visit <u>entegris.com</u> and select the <u>Contact Us</u> link to find the customer service center nearest you.

CONTENT AND LIABILITY DISCLAIMER

Entegris believes the information in this document is accurate as of its publication date. Any and all specifications and designs are subject to change without notice. Entegris is not liable for errors or omissions in this document. Entegris undertakes no obligation to update the information presented in this document. You may not use or facilitate the use of this document in connection with any infringement or other legal analysis concerning Entegris products described herein. You agree to grant Entegris a non-exclusive, royalty-free license to any patent claim thereafter drafted which includes subject matter disclosed herein. No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted by this document.



Corporate Headquarters 129 Concord Road Billerica, MA 01821 USA
 Customer Service

 Tel
 +1
 952
 556
 4181

 Fax
 +1
 952
 556
 8022

 Toll Free
 800
 394
 4083

Entegris[®], the Entegris Rings Design[®], and other product names are trademarks of Entegris, Inc. as listed on <u>entegris.com/trademarks</u>. All third-party product names, logos, and company names are trademarks or registered trademarks of their respective owners. Use of them does not imply any affiliation, sponsorship, or endorsement by the trademark owner.

©2020 Entegris, Inc. | All rights reserved. | Printed in the USA | 9000-11045ENT-0520